



The Critical Path in Maintenance Starts and Ends With Bolting.

TOOL MODEL: TTP-.25 PRESSURE / TORQUE CONVERSION CHART

PRESSURE		TORQUE		
psi	bar	ft-lbs	kgf-m	N-m
20	1.38	48	7	65
25	1.72	60	8	82
30	2.07	72	10	98
35	2.41	84	12	114
40	2.76	96	13	130
45	3.1	112	15	151
50	3.45	128	18	174
55	3.79	144	20	196
60	4.14	161	22	218
65	4.48	172	24	233
70	4.83	183	25	248
75	5.17	193	27	262
80	5.52	205	28	278
85	5.86	232	32	314
90	6.21	259	36	351

