

TORCTOOL

TOOL MODEL: TTX-1

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	168	23	228	104
1600	180	25	244	110
1800	203	28	276	124
2000	227	31	308	138
2200	252	35	341	152
2400	276	38	374	165
2600	301	42	408	179
2800	325	45	441	193
3000	350	48	474	207
3200	375	52	508	220
3400	400	55	542	234
3600	424	59	575	248
3800	449	62	609	262
4000	474	66	643	276
4200	499	69	676	290
4400	523	72	709	303
4600	548	76	743	317
4800	572	79	776	331
5000	597	83	809	345
5200	622	86	843	358
5400	647	89	877	372
5600	672	93	911	386
5800	697	96	945	400
6000	722	100	979	414
6200	748	103	1013	427
6400	773	107	1048	441
6600	799	110	1083	455
6800	824	114	1118	468
7000	850	118	1152	482
7200	879	122	1191	496
7400	907	125	1230	510
7600	936	129	1269	524
7800	964	133	1307	538
8000	993	137	1346	552
8200	1016	141	1377	565
8400	1039	144	1408	579
8600	1062	147	1440	593
8800	1085	150	1471	607
9000	1108	153	1502	620
9200	1133	157	1536	634
9400	1159	160	1571	648
9600	1184	164	1605	662
9800	1210	167	1640	676
10000	1235	171	1674	690