

TORCTOOL

TOOL MODEL: TTX-3

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	446	62	604	104
1600	477	66	646	110
1800	539	75	730	124
2000	601	83	814	138
2200	662	92	897	152
2400	723	100	980	165
2600	784	108	1063	179
2800	845	117	1145	193
3000	906	125	1228	207
3200	969	134	1313	220
3400	1032	143	1399	234
3600	1095	151	1484	248
3800	1158	160	1570	262
4000	1221	169	1655	276
4200	1282	177	1737	290
4400	1343	186	1820	303
4600	1403	194	1902	317
4800	1464	202	1985	331
5000	1525	211	2067	345
5200	1589	220	2154	358
5400	1653	229	2241	372
5600	1718	238	2328	386
5800	1782	246	2415	400
6000	1846	255	2502	414
6200	1908	264	2586	427
6400	1969	272	2669	441
6600	2031	281	2753	455
6800	2093	289	2837	468
7000	2154	298	2920	482
7200	2217	307	3005	496
7400	2280	315	3091	510
7600	2343	324	3176	524
7800	2406	333	3261	538
8000	2468	341	3346	552
8200	2532	350	3432	565
8400	2595	359	3517	579
8600	2658	368	3603	593
8800	2721	376	3689	607
9000	2784	385	3774	620
9200	2847	394	3860	634
9400	2911	403	3945	648
9600	2974	411	4031	662
9800	3037	420	4117	676
10000	3100	429	4202	690