

TORCTOOL

TOOL MODEL: TTX-7

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	1178	163	1597	104
1600	1260	174	1707	110
1800	1423	197	1929	124
2000	1586	219	2151	138
2200	1750	242	2373	152
2400	1914	265	2595	165
2600	2078	287	2818	179
2800	2242	310	3040	193
3000	2406	333	3262	207
3200	2577	356	3493	220
3400	2748	380	3725	234
3600	2918	404	3956	248
3800	3089	427	4187	262
4000	3259	451	4418	276
4200	3431	475	4651	290
4400	3603	498	4884	303
4600	3775	522	5117	317
4800	3947	546	5350	331
5000	4119	570	5583	345
5200	4288	593	5813	358
5400	4457	616	6042	372
5600	4626	640	6272	386
5800	4796	663	6501	400
6000	4965	687	6731	414
6200	5137	710	6964	427
6400	5310	734	7198	441
6600	5482	758	7431	455
6800	5654	782	7665	468
7000	5826	806	7898	482
7200	5999	830	8132	496
7400	6172	854	8366	510
7600	6344	877	8600	524
7800	6517	901	8834	538
8000	6689	925	9068	552
8200	6865	949	9306	565
8400	7040	974	9544	579
8600	7216	998	9781	593
8800	7391	1022	10019	607
9000	7566	1046	10257	620
9200	7741	1071	10493	634
9400	7915	1095	10729	648
9600	8089	1119	10965	662
9800	8263	1143	11201	676
10000	8437	1167	11437	690