

TORCTOOL

TOOL MODEL: TTZ-14

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	2062	285	2795	104
1600	2203	305	2987	110
1800	2485	344	3369	124
2000	2767	383	3751	138
2200	3059	423	4146	152
2400	3350	463	4541	165
2600	3641	504	4936	179
2800	3933	544	5331	193
3000	4224	584	5726	207
3200	4509	624	6113	220
3400	4795	663	6500	234
3600	5080	703	6886	248
3800	5365	742	7273	262
4000	5650	781	7659	276
4200	5948	823	8063	290
4400	6246	864	8467	303
4600	6544	905	8871	317
4800	6842	946	9275	331
5000	7140	987	9679	345
5200	7437	1029	10082	358
5400	7735	1070	10485	372
5600	8032	1111	10888	386
5800	8329	1152	11291	400
6000	8626	1193	11694	414
6200	8925	1234	12098	427
6400	9223	1276	12503	441
6600	9521	1317	12907	455
6800	9820	1358	13311	468
7000	10118	1399	13716	482
7200	10415	1440	14119	496
7400	10713	1482	14523	510
7600	11011	1523	14926	524
7800	11308	1564	15329	538
8000	11606	1605	15733	552
8200	11915	1648	16152	565
8400	12224	1691	16570	579
8600	12533	1733	16989	593
8800	12842	1776	17408	607
9000	13151	1819	17827	620
9200	13436	1858	18214	634
9400	13721	1898	18600	648
9600	14006	1937	18987	662
9800	14291	1976	19373	676
10000	14576	2016	19760	690